



COLD WEATHER HAZARDS OF PROPANE FUELED VEHICLES

EMPIRE
PACIFIC

Risk Management, Inc.

Company Name _____

Date _____

Propane is a gas that is turned into a liquid when stored in pressurized cylinders. You should be aware that as the temperature of the fuel tank rises, the liquid fuel expands which increases pressure inside the tank. In cold weather this could result in a fire or explosion if a propane-powered vehicle with more than 80% liquid fuel in the fuel tank is brought into a heated building from outside. The increased air temperature in the shop causes increased pressure inside the fuel tank. This will open the safety relief valve if the tank has been overfilled, and the released propane gas can burn if any ignition sources are present.

General Safety Precautions When Servicing Propane Fuel Vehicles In Cold Weather:

1. Before bringing a propane-fueled vehicle indoors for service be sure the propane system is leak-free. In weather above freezing use a soap and water solution to check connections, valves, and lines. In colder weather use a commercial leak detector solution that is available from safety supply houses, or use a combustible gas indicator that is calibrated for propane.
2. Be sure the fuel tank is not filled beyond the maximum recommended filling capacity (usually 80%). The level of liquid fuel can be checked as follows:
 - o Park the vehicle on a level area outdoors with no possible sources of ignition nearby.
 - o While wearing neoprene gloves, disconnect the fuel line and briefly open the tank valve. If the container is safely filled you will hear an audible hiss when the valve is opened. No white fog will appear.
 - o If the tank is *overfilled*, you will see a white fog when the valve is opened.
 - o If the tank is overfilled, do not take the vehicle indoors until the liquid level is reduced below 80%. Consider letting the vehicle run to accomplish this.
 - o When the liquid has reached a safe level, recheck all valves, especially the pressure relief valve to be sure there are no leaks before moving the vehicle indoors.
3. The fuel lines should be free of fuel when the vehicle is indoors for repairs or servicing. Fuel lines should be charged only when propane is required to operate the engine. The procedure is:
 - o Turn the tank valve to the closed position. Clockwise closes the valve.
 - o Allow the engine to operate until it stops from lack of fuel.
4. When repair or service work has been completed, recharge the fuel line:
 - o Open the fuel line valve VERY SLOWLY, until the line fills with propane.
 - o If the excess flow valve should close, shut off the tank valve and wait 10 - 15 seconds for the valve to reset. Then, SLOWLY open the tank valve again.
5. If propane gas is released in an enclosed area (for example, if the relief valve opens), the following actions should be quickly taken:

5300 SW Meadows - Suite 220 - Lake Oswego, Oregon 97035
Phone 503 968-6300 www.empirepac.com Fax 503 968-6305

Courtesy of TOOLBOXTOPICS.COM

- Evacuate the area.
 - Remember that propane vapors are heavier than air and will settle at floor level.
 - Eliminate all sources of ignition (torches, water heaters, pilot lights, cigarettes)
 - Close off the source of the leak if possible and open all doors to ventilate the area.
 - Do not restart any ignition sources until after the propane odor has been eliminated.
6. Be sure to follow all safe operating procedures as recommended by the equipment manufacturer and consult with them, and/or the distributor if you have questions.

Safety Recommendations: _____

Job Specific Topics: _____

M.S.D.S Reviewed: _____

List of Attendees

_____	_____
_____	_____
_____	_____
_____	_____
_____	_____